



BUILD-IN COOKING HOB

MODEL H200F/300F/400F/756S/900

WARNING

- Only use this appliance in a well ventilated area.
 - Read the instructions before use.
- This appliance must be installed by a **competent person**.

User and Installation Instructions

PLEASE READ THOROUGHLY and keep for future reference.

FOR USE IN GREAT BRITAIN/IRELAND

SPINFLO LIMITED, 4-10 Welland Close, Parkwood Industrial
Estate, Rutland Road, Sheffield S3 9QY.
TEL: 0114 273 8157 FAX: 01142753094

BUILD IN COOKING HOB
MODEL H200F/300F/400F/756S/900

INTRODUCTION

This appliance shall be installed in accordance with the regulations in force and only in a well ventilated space. Read the instructions before installing or using this appliance
This cooker must be installed according to the relevant local and national regulations in force Failure to install the appliance correctly could invalidate any warranty or liability claims and lead to prosecution.
Note: An appliance for LP gas shall not be installed in a room or internal space below ground level e.g. in a basement.

VENTILATION

This appliance must be installed according to the relevant local and national/European standards in force
This appliance is suitable for installation into Holiday Homes, Touring Caravans and Boats. In all cases the national standards with regard to ventilation for the particular vehicle into which the appliance is to be installed must be adhered to

IMPORTANT

This appliance is suitable for use with Liquid Petroleum Gas (LPG) and should not be used on any other gas. The following gas pressures should be used:-

CAT I₃ + (28-30137) CAT I₃ B/P (30)
BUTANE (G30) 28-30 mbar BUTANE (G30) 30 mbar
PROPANE (G31) 37 mbar PROPANE (G31) 30 mbar

POSITION

This appliance must be positioned free from draughts, which may affect the combustion, and in a manner that will prevent the accumulation of unburnt gas. When in use ensure that air vents are not inadvertently blocked or shut off.

USER'S INSTRUCTIONS

OPERATION

Burners- Each burner is controlled individually and may be monitored by a flame failure sensing device. The respective knob positions are as shown below -



To light the burner, depress and turn the knob anti-clockwise to the full rate position, apply a light to the burner or press the ignition button if fitted. On models with the flame sensing device it is necessary to hold the knob depressed during ignition and for approximately fifteen seconds after the burner has lit to allow the probe to reach temperature. Should the flame go out when the knob is released, the procedure should be repeated holding the knob depressed for slightly longer. In the event of the burner flames being accidentally extinguished, turn of the burner control and do not attempt to re-ignite for at least 1 minute. If required the knob can be turned further anti-clockwise to the simmer position,
To turn the burner off, rotate the knob fully clockwise until the dot on the knob lines up with the dot on the fascia.

The burners on this appliance have fixed aeration and no adjustment is required.

Depending on the gas being used, the burners should flame as follows:

Propane- The flames should burn quietly with a blue/green colour and no sign of yellow tips.

Butane- Normally on initial lighting, a small amount of yellow tipping will occur and then slightly increase as the burner heats up.

Although the burner will support pans from 12 to 22cm, care should be taken not to overload the appliance as reduced performance may result.

When using small pans the flame should not spread beyond the base of the pan as this will reduce the efficiency of the burner.

SAFETY

It is important that ordinary safety precautions be observed in the use of this appliance.

- 1) When cooking keep children away from the vicinity. Turn pan handles inwards so they cannot be caught accidentally.
- 2) Never leave fat or oil unattended on the hotplate.
- 3) When finished, check that all controls are in the off position.
- 4) This appliance must not in any circumstances be used as a space heater.
- 5) If fitted in a touring caravan or motor van, all burners should be extinguished when the vehicle in which the appliance is installed is moving. It is preferred that the cylinder valve to the appliance be turned off.

LEAKS

If a smell of gas becomes apparent, the supply should be turned off at the cylinder IMMEDIATELY. Extinguish naked lights including cigarettes and pipes Do not operate electrical switches. Open all doors and windows to disperse any gas escape.

Butane/Propane gas is heavier than air, any gas escaping will therefore collect at low level. The strong unpleasant smell of gas will enable the general area of the leak to be detected. Check that the gas is not escaping from an unlit appliance.

Never check for leaks with a naked flame, leak investigation should be carried out using a leak detector spray or soapy solution

MAINTENANCE

This appliance needs little maintenance other than cleaning. All parts should be cleaned using warm soapy water.

Do not use abrasive cleaners, steel wool or cleansing powders. When cleaning the burner ring it is essential to ensure that the holes do not become blocked.

The control knobs are a push fit and can be removed for cleaning. They are interchangeable without affecting the sense of operation.

On units fitted with battery spark ignition, when the time taken for spark generation becomes extended, the battery should be renewed with a suitable make of long life battery.

THIS APPLIANCE MUST NOT BE MODIFIED OR ADJUSTED UNLESS AUTHORISED AND CARRIED OUT BY THE MANUFACTURER OR HIS REPRESENTATIVE.

NO PARTS OTHER THAN THOSE SUPPLIED BY THE MANUFACTURER SHOULD BE USED ON THIS APPLIANCE.

INSTALLATION INSTRUCTIONS

In your own interest of safety, it is law that all gas appliances be installed by competent persons. CORGI (Confederation for the Registration of Gas Installers) registered installers undertake to work to safe and satisfactory standards. Failure to install the appliance correctly could invalidate any warranty or liability claims and lead to prosecution. This appliance shall be installed in accordance with the local and national/European standards in force. Particular attention shall be given to the requirements regarding ventilation, Read the instructions before installing or using this appliance.

VENTILATION

This appliance must be installed according to the relevant local and national/European standards in force. This appliance is suitable for installation into Holiday Homes, Touring Caravans and Boats In all cases the national standards with regard to ventilation for the particular vehicle into which the appliance is to be installed must be adhered to.


INSTALLATION

A cut out should be prepared in the worktop as shown below. Heat barriers must be fitted to the front and back edges where indicated. The unit should not be fitted in a position exposed to strong draughts, since this always reduces the efficiency of the burners.


Model 300E stainless steel should be fixed using a countersunk woodscrew in each corner.

Model 300F enamel should be fixed using the screw clips provided

Model 200F




Model 300F




Model 400F




Model 756S



Model 400F & 7565




Model 200F/400F/756S




Models 200F/400F/756S should be fixed in position using a countersunk woodscrew (UK No. 6) fitted through the pan rest clips as shown.


Model 900



Section B-B



Section B-B shown with hob fixed in place using the fixing bushes provided.



All Models

A direct distance of 200mm (7.9") must exist between the edge of the appliance burners and any combustible material, unless protected by a layer of non-combustible material.

All combustible materials such as curtains and shelves must be kept well clear of the appliance. Any fitments such as a cupboard above the unit must have a minimum clearance of 500mm (20") between the fitment and the top of the pan rest

The underside of the appliance must be shielded. It is recommended that the shield be fabricated from non-combustible material, but if the enclosure is manufactured from combustible material, then a minimum air space of 100mm (4") must exist between the material and the lowest part of the appliance.

THIS AIR SPACE MUST BE WELL VENTILATED.

CONNECTION

An 8mm gas inlet point is provided on the underside of the appliance. It is recommended that the unit be connected by copper tubing using an appropriate connector. A rubber connection must not be used.

After connection the appliance must be tested for soundness.

This appliance is suitable for use on LPG at the following pressures –

BUTANE	28mbar (11.2wg)
PROPANE	37mbar (14.8wg)

It is important that the regulator should be set to the correct pressure for the type of gas being used. Excessive pressure must not be permitted.

If the flame on the burners show a tendency to lift, it is probable that the line pressure is too great. Should there be excessive yellow tips (resulting in sooting), then it is probable that the line pressure is too low and in either case the burners should not be used until the line pressure has been checked.

This appliance is fitted with the following injectors:

BURNERS	0.62mm 1.5kW
---------	--------------

The burners on this appliance have fixed aeration and no adjustment is necessary.