

Lab-Craft Water-Pump Installation

- a. Fix pump in vertical position on the floor or on the wall. The mounting shoe on the base can be removed by rotating it a quarter turn in relation to the main body.
- b. Secure the shoe in the required position by fixing with screws and washers through the rubber bushes. Do not overtighten these screws.
- c. To mount the pump on the wall the shoe has been designed such that it will also lock into the T-shaped opening in the side of the pump body.
- d. The pump may be operated from a 12V dry battery or a 12V car battery (rechargeable).

Keep positive (+) to RED, and negative (-) to BLACK.

Use thick wall plastic pipe to prevent kinks or sharp bends.

All pipe connections (except the input filter) should be secured by suitable pipe-clips (Jubilee 00).

A Lab-Craft Pressure Switch is available for the water pump.

